

Mucool Test Area

Cryostat & cooling-loop design

Christine Darve

Fermilab/Beams Division/ Cryogenic Department/ Engineering and Design Group



MuCool / MICE

02/21/03


**MuCool
MICE**


Absorber
window

Vacuum
window




MuCool Test Area





Cryostat design



The Linac beam will deposit within the absorber a maximum heat deposition of
150 Watt

$P = 1.2 \text{ atm,}$


$T = 17 \text{ K}$

$\Delta p < 5\%$

$\Delta T \sim 1 \text{ K (could be 3 K)}$

◆ Safety guidelines:

1. "Guidelines for the Design, Fabrication, Testing, Installation and Operation of LH2 Targets–20 May 1997", Fermilab by Del Allspach et al.
2. Fermilab ES&H (5032)
3. code/standard ASME, NASA
4. NEC (art 500)
5. CGA



1. Caltech LH2 pump


- Max LH2 mass-flow = 450 g/s (0.12 MPa, $T_{in}=17$ K)
- ΔP total < 0.36 psig

References :

1. “A high power liquid hydrogen target for parity violation experiments”, E.J. Beise et al., *Research instruments & methods in physics research* (1996), 383-391”
2. “MuCool LH2 pump test report”, C. Darve and B. Norris, (09/02)





2. Lab-G magnet







Conceptual Design





Heat load calculations




Legend:

- Heat transfer by conduction through supports
- Heat transfer by radiation and through MLI

Heat load (W)	80 K	17 K
Mechanical Supports	67	6
Superinsulation	1.5	0.2
Cryostat windows	-	17
LH2 pump	-	50
Total	68.5	73.2



"Materials list" - Cryostat Design



The MTA cryostat is mainly composed of:

Cryogens used:

- LN2 to cool Thermal shield
- Ghe to cool LH2 cryo-system
- LH2 to cool cryo-system (beam+static)

	P (psia)	T(K)	m_max (g/s)
N2	45.0	77-80	5
He	32.0	14-17	26
H2	17.6	17-20	450


- LH2 Absorber
- Vacuum vessel
- Thermal shield
- Hydrogen buffer
- Vacuum window
- Transfer lines
- Safety devices
- Heat exchanger
- LH2 pump
- Motor
- Supports
- Equipment





FERMILAB


BD/Cryogenic Department

Assembly




- ✓ Vacuum vessel: MAWP=25 psig;
SS, 16 IPS Sch10, 48 IPS Sch10
 - Dome (SS, 0.25 inch)
 - Plate (SS, 0.25 inch)
 - Central support (1 inch)
- ✓ Thermal shield (Al) +MLI (Al, Mylar)
 - Aluminum braids
 - Aluminum cooling line
- ✓ He, H2 and N2 Piping (SS, 1-2 inch IPS)
- ✓ Hydrogen buffer(SS, ϕ 3 inch)
- ✓ Vacuum window Flange, Al, SS, Al seal
- ✓ Vacuum pump flange
- ✓ Relief vacuum





Pressure safety devices



Pressure relief valve – LH₂ : II C 4 a (iii)

- ◆ Relief pressure (10 psig or 25 psid)
- ◆ Sized for max. heat flux produced by air condensed on the LH₂ loop at 1 atm.

2 valves ACGO
ASME code
Capacity = 52 g/s

=> 0.502 inch²
Redundant

Pressure relief valve – Insulation vacuum : II D 3

- ◆ MAWP (15 psig internal)
- ◆ Capable of limiting the internal pressure in vacuum vessel to less than 15 psig following the absorber rupture (deposition of 25 liter in the vacuum space)
- ◆ Vapor evaluation $q = 20 \text{ W/cm}^2$
- ◆ Take into account DP connection piping and entrance/exit losses


3 parallel plates (FNAL design)
Calculated Capacity = 197 g/s

=> 2 inch
Redundant

Relief system must be flow tested




MTA Cryostat Design



1. Heat exchanger assembly

- ✓ Coil (copper, ϕ 0.55 inch)
- ✓ Outer shell (SS, 6 inch tube)



2. LH2 pump assembly


- ✓ LH2 pump and shaft with foam
- ✓ Motor outer shield

3. Absorber assembly:

- ✓ Black/Wing windows and manifold design
- ✓ Interface of the systems
 - Bimetallic junction
 - Indium Doubled-seal

4. Supports

- ✓ G10 spider and rods






February 21 2003



FERMILAB

BD/Cryogenic Department

Comments/questions




1. Cryo-pumping
2. Position of cryostat vacuum windows
3. Interfaces: atmosphere or vacuum behind cryostat vacuum windows
4. Absorber Instrumentation routing and ports



FERMILAB

BD/Cryogenic Department


MTA Cryostat design – Conclusions




Cryostat 3D model current focuses:

- ✓ Change orientation of the heat exchanger
- ✓ Final LN2 cooling system
- ✓ Implementation of vacuum windows
- ✓ Heater implementation
- ✓ Supports
- ✓ Instrumentation implementation

As it looks today





Cooling-loop design


(Introduction to Oxford analysis)





FERMILAB

BD/Cryogenic Department

Cooling-loop Design



Manifold optimization of nozzle distribution and geometry



Flow Simulation by Wing Lau/ Stephanie Yang (Oxford)


1. Simulate MTA manifold geometry
2. Simulate beam at 150 W (vol. deposition, $\varnothing 10\text{mm}$, 3 sigma gaussian)
3. Calculate heat transfer coefficients and temperature distribution for MTA conditions (DV $\sim 0.5\text{ m/s} - 4\text{ m/s}$)



FERMILAB

BD/Cryogenic Department


Pressure drop calculations



Study of the thermo-hydraulic behavior in LH2 absorber

w/ $\Delta T = 1$ K

Will a velocity at the nozzle lower than 2 m/s be enough for ionization cooling (i.e. $\Delta T < 1$ K)?



$\dot{m} = 450$ g/s

11 supply / 15 return nozzles

Nozzle dia. = 0.6 inch



Nozzle supply velocity = 3 m/s

Maximum allowable DP = 0.364 psi


Total DP calculated = 0.301 psi



FERMILAB
BD/Cryogenic Department

Temperature distribution simulation

By Wing Lau and Stephanie Yang (Oxford)





Model A

11 supply nozzles

15 return nozzles

Nozzle diameter: 0.43 inch







FERMILAB



BD/Cryogenic Department

Temperature distribution simulation

By Wing Lau and Stephanie Yang (Oxford)



$$\Delta T < 1 \text{ K}$$



Model A

$V_{\text{sup}} = 2 \text{ m/s}$

But ...

DP = 90 psi

(DP adm. = 76psi)





FERMILAB


BD/Cryogenic Department

Temperature distribution simulation

By Wing Lau and Stephanie Yang (Oxford)




$$\Delta T < 1 \text{ K}$$



Model A

$V_{\text{sup}} = 0.5 \text{ m/s}$



Lower limit for
the solution with
 $m_{\text{dot}} = 38 \text{ g/s}$




FERMILAB

BD/Cryogenic Department

Temperature distribution simulation

By Wing Lau and Stephanie Yang (Oxford)





Model B

8 supply nozzles

12 return nozzles

Nozzle diameter: 0.63 inch







FERMILAB


BD/Cryogenic Department

Temperature distribution simulation

By Wing Lau and Stephanie Yang (Oxford)



$$\Delta T < 1 \text{ K}$$



Model B

$V_{\text{sup}} = 2 \text{ m/s}$


But ...

$\Delta P = 0.101 \text{ psi}$

($\Delta P_{\text{adm.}} = 0.119 \text{ psi}$)



MTA cooling loop system – Conclusions



		Model A	Model A	Model B	Model C	Model C	Model C
d_nozzle	inch	0.43	0.43	0.63	0.60	0.60	0.60
Abs_id	inch	22	22	22	21	21	21
#_supply		11	11	8	11	11	11
#_return		15	15	12	15	15	15
m_dot	g/s	152	38	215	300	75	450
V_sup	m/s	2.000	0.500	2.000	2.000	0.500	3.039
V_ret	m/s	1.470	0.370	1.330	0.193	0.370	2.230
D_P	psi	90.000	5.900	0.101	0.137	0.009	0.301
D_Ppump	psi	76.000	22.000	0.119	0.380	0.036	0.364
D_T	K	0.380	1.000	0.150	?	?	?

Cooling loop Focuses: Proposed Solution: 11 supply/15 return, Dia 0.6"

The Model A proves that $\Delta T=1K$ is achieved if nozzle velocity is 0.5 m/s

Therefore any configuration with at least 26 nozzles, larger then 0.43 inch diameter will meet our requirement.

Model C will permit us to cross-check the current solution.



Process Instrumentation Diagram

