



- **27.Oct.2009 Excel spreadsheet contains data from all three regions, from the last few years**
  - KEK [5 cavities]: [MHI005:MHI009]
  - JLab, Cornell, Fermilab [18 cavities]: [A5: A9], [TB9ACC010:TB9ACC015], [AES001:AES004], [TB9AES005:TB9AES006], JLAB-2
  - DESY [53 cavities]: [AC112:AC129], [Z130:Z145], [AC146:150]  
(Production batches 5, 6, &7 are represented) and  
[Z88,Z93,Z97,Z98,Z100:Z104,Z106:Z110] (Production 4)
- **11.Dec.2009 update**
  - Updates from all three regions
  - Americas [+3 cavities]: TB9AES008,TB9AES009,TB9AES010

- Database version 11.Dec.2009
- Cuts
  - Cavity from qualified vendor= ACCEL or ZANON or (AES SN $\geq$ 5)
  - Fine-grain cavity
  - Use the first successful (= no system problem/limitation) test
  - Standard EP processing: no BCP, no experimental processes
    - Defined as JLab#1, DESY#2 (weld tank before test), DESY #4 (weld tank after test)
    - Ethanol rinse and 120C bake required for DESY cavities
  - (Ignore test limitation)
- Also known as “first-pass”
- Include binomial errors



# Difference of AAP plot wrt ADI



**ADI 2.Dec.2009**


Plot 1c: 1st successful	
cavity name	gradient
ACCEL6	19 >15
ACCEL7	29 >25
TB9ACC011	37 >35
TB9ACC012	35.1 >35
TB9ACC013	41.8 >40
TB9ACC014	26 >25
TB9ACC015	18 >15
Z88	32.14 >30
Z93	22.46 >20
Z97	26.17 >25
Z101	29.2 >25
Z102	26.75 >25
Z104	37.84 >35
Z106	30.05 >30
Z108	22.85 >20
Z110	13.78 >10
AC115	38.6 >35
AC122	38.88 >35
AC124	26.01 >25
AC125	34.59 >30
AC126	16.37 >15
AC127	31.25 >30
Z130	17.3 >15
Z131	17.17 >15
Z132	16.83 >15
Z137	25.23 >25
Z139	24.93 >20
Z141	18.29 >15
Z143	32.57 >30
AC149	26.51 >25
AC150	34.33 >30
#cavities	31

Plot 1d-prime: 1st successful	
cavity name	gradient
ACCEL6	19 >15
ACCEL7	29 >25
TB9ACC011	37 >35
TB9ACC012	35.1 >35
TB9ACC013	41.8 >40
TB9ACC014	41.5 >40
TB9ACC015	18 >15
TB9ACC016	30.6 >30
TB9AES005	20.5 >20
TB9AES006	14.1 >10
TB9AES008	41.1 >40
TB9AES009	33.4 >30
TB9AES010	38 >35
AC115	38.6 >35
AC122	38.88 >35
AC124	26.01 >25
AC125	34.59 >30
AC126	16.37 >15
AC127	31.25 >30
Z130	17.3 >15
Z131	17.17 >15
Z132	16.83 >15
Z134	34.94 >30
Z137	25.23 >25
Z139	24.93 >20
Z141	18.29 >15
Z142	20.58 >20
Z143	32.57 >30
AC149	26.51 >25
AC150	34.33 >30
#cavities	30


**AAP 6-7.Jan.2010**

removed  
added  
changed


Electropolished 9-cell cavities



Electropolished 9-cell cavities




Electropolished 9-cell cavities




- Database version 11.Dec.2009
- Cuts
  - Cavity from qualified vendor: ACCEL or ZANON or (AES SN $\geq$ 5)
  - Fine-grain cavity
  - Use the first successful (= no system problem) test
  - Standard EP processing: no BCP, no experimental processes
    - Defined as JLab#1, DESY#2 (weld tank before test), DESY #4 (weld tank after test)
  - (Ignore test limitation)
  - Second pass
    - if (Eacc(1<sup>st</sup> successful test) $<$ 35 MV/m) then
      - if (2<sup>nd</sup> successful test exists) then
        - » plot 2<sup>nd</sup> test gradient
      - else
        - » plot nothing [assume 2<sup>nd</sup> test didn't happen yet]
      - endif
    - else
      - plot 1<sup>st</sup> successful test gradient
    - endif
- Include binomial errors


Electropolished 9-cell Cavities



Electropolished 9-cell cavities




Electropolished 9-cell cavities





## Electropolished 9-cell cavities

JLab/DESY first successful test of cavities from qualified vendors - ACCEL+ZANON+AES (30 cavities)



## Electropolished 9-cell cavities

JLab/DESY (combined) up-to-second successful test of cavities from qualified vendors - ACCEL+ZANON+AES (25 cavities)



**yield is improved after 2<sup>nd</sup> pass**